Sharpak 35 PLUS assembly instructions

To assemble, place on a firm flat surface at a comfortable working height.

1

Ensure that the HYDRI mat is inside the container before assembling.

Position the lid ensuring that the word 'FRONT' faces the handle and label ...

2

... now place the lid onto the base ensuring that the inner seal of the lid is inserted into the base ...

3

... NOW press down all four corners fully in turn, in the sequence shown to secure the lid to the base. Double check that the side latches are also engaged.

4 clicks and you're there!

CODE ORANGE CODE YELLOW CODE PURPLE SHARPAK™ HEALTHCARE

Patented and trademarked by Nolato.

For details regarding Sharpak distributors and worldwide availability, please contact:

Tel +44 2392 314711 Fax +44 2392 380314 www.sharpaks.com

Inpress Plastics Ltd